

Shoe & Boot Covers Material Selection

SUPERIOR QUALITY, PERFORMANCE, AND DURABILITY

SHOE & BOOT COVERS

Material Options

| | |
|-----------------------------|---|
| AquaTrak® | superior anti-skid properties for use in wet and/or dry environments |
| SureGrip® | durable material with outstanding inherent anti-skid properties for dry environments |
| SureGrip® Conductive | same high quality SureGrip material with Conductive Strip |
| GenPro® | economical polypropylene material for a variety of general purpose applications |
| CPE | CPE or 'Film' material shoe covers are ideal for boot-cover liners, contractors, and visitors |

Seam Options

| | |
|---------------------|--|
| Serged | threads are interlocked around the material edges for a strong, stress-resistant seam |
| Sonic Welded | material is welded together creating a superior particle and fluid barrier |
| Heat-Sealed | strong and impervious, this seam is used when Ultrasonic welding is incompatible with the garment material |

Sole Options

| | |
|----------------------------------|---|
| UltraGrip™ Anti-Skid | ultimate anti-skid sole material for use in high risk, slip and fall application |
| SafeStep® Anti-Skid | environmentally friendly sole shoe cover material with high anti-skid properties |
| MaxGrip® Anti-Skid | ideal sole material for use in many different environments on a variety of floor surfaces |
| Seamless, Butterfly Style | provides a smooth, seamless sole for better traction and fluid resistance |

BOOT COVERS

Secure Options

| | |
|-----------------------------------|---|
| Elastic Top, Ankle Ties | secure fit with elastic top, custom tie closure around ankle |
| Elastic Top, Elastic Ankle | secure fit with elastic top and around ankle for easier donning |

*Not all options are available with all shoe and boot covers.



Shoe Covers



Boot Covers